



Recommended to use two of the same sensors with one controller.

- A: Actuator Cable (High Current)
M12 4-pin T-coded Male and Female cordset*
- S: Servo Center Sensor
M8 6-pin Female to Inductive Proximity Sensor*
- M: Motor Communication Cable
M8 4-pin Female-Female cordset (shielded + Twisted Pair)*
- SC: Quick Disconnect Sensor Cable
M12 12-pin shielded cable Male and Female cordset*
- P: 24 V DC Input Power Cable
DC Power Connector 2.5mm tip for 24V DC Power Flying Lead*
- P: 24V/48V DC Driver Power Cable
M12 4-pin S-Coded Male for Driver Power with Flying Lead*

Web Guide Actuator or Unwind/Rewind Actuator